

# THREE-PHASE TRANSFORMER CONNECTIONS – Usual Types

0	<p>Yy0</p>	<p>Dd0</p>	<p>Dz0</p>
1	<p>Yd1</p>	<p>Dy1</p>	<p>Yz1</p>
5	<p>Yd5</p>	<p>Dy5</p>	<p>Yz5</p>
6	<p>Yy6</p>	<p>Dd6</p>	<p>Dz6</p>
11	<p>Yd11</p>	<p>Dy11</p>	<p>Yz11</p>